



1. Mix the Part A and Part B like a conventional burst pouch.
2. After mixed, roll the burst pouch toward the secondary burst seal, applying pressure until the secondary burst seal ruptures allowing mixed material into the detachable pour spout.
3. Tear perforation to detach the pour spout
4. Pull across at tear notch
5. Dispense material using directional pour spout